

## SEATBELT ADJUSTER.



The Seatbelt Adjuster clips onto the waist area of your seat belt instantly, and spares you hours of discomfort on the road. Designed to slide approx. 3 to 5 inches on the seat belt waist area, it holds the shoulder strap away from your neck and chest area with no loss of safety. Wonderful on long trips! Motivates people to use the seatbelt properly.

## The Seatbelt Adjuster can remain fastened to the lap belt permanently.










Fig. 1: Attach the Seatbelt Adjuster to the lap part of the belt by centering the belt between the hinged tongue and the front part of the clasp.

Fig. 2: Snap the back tongue securely in place by pressing the two pieces together until you hear a sharp clicking sound.

**Fig. 3:** Slip the shoulder belt under the front tongue of the Seatbelt Adjuster and slide the Adjuster to a comfortable position until the shoulder strap is away from your neck.

**Note** Do not slide the Seatbelt Adjuster more than 3" to 5" away from the buckle clasp.



